

Installing pre-framed Illuminado windows

1. Before ordering your windows, measure your window opening carefully, taking the distance from brick to brick and subtracting 1/2" from both width & height to ensure proper fit.

2. Insulated vinyl windows come to you well crated and protected with a cardboard cover

3. Carefully pry away vinyl strip before placing your window in your opening

4. Using helpers on both sides of the window carefully set your window into place. Shim and level window until it is stable

5. At a straight angle, drill into your window in the cavity where your vinyl strip came from. Then secure the window in place using 3 1/2" screws drilled directly into your brick

6. Apply polyurethane caulk to the outside of the window between brick and frame to weatherproof wiping off any excess caulk.